



Safety

WARNING

- Do not stand on or in this product. You may fall which can cause personal injury.
- Wear Safety Glasses when removing or repositioning the cabinets and drawers.
- When moving this product, do not pull it. Push the product to prevent personal injury.
- Use the brakes when not moving this product. This will prevent the product from rolling.
- Be careful not to open more than one drawer at a time. This product may become unstable and tip.
- Handle and swivel casters must be attached properly to the cabinet.
- Do not alter this product in any manner.
- Keep this product on level surfaces, this product may become unstable and tip if stored or moved on an un-level surface.

Assembly

Caster and handle installation

Note

Use adequate manpower for this operation.

Make sure that the cabinet is empty prior to installing the casters and handles.

Casters

- 1. Lay the cabinet down on its top. Use packaging material to protect the paint finish.
- 2. Mount both swivel casters on the back side of the cabinet and the locking caster to the front (drawer side).
- 3. Attach each caster using four bolts per cabinet for the casters and two for each handle.
- 4. Wrench tighten all bolts.
- 5. Return cabinet to its upright position.
- 6. See Figure A-1, for final assembled cabinet.



Figure A-1

Multi-side by side assembly

- 1. Attach casters as noted above.
- 2. Attach 1 handle to each end of cabinet.
- 3. Use hinge pins to attach cabinets to each other.
- 4. See Figure A-2 for final assembled cabinet.
- 5. The Cabinet assembled in this manner will slide under the Mark V unit, see figure A-3.



Figure A-2



Figure A-3

Vertical assembly of multiple cabinets.

- 1. Attach casters on bottom unit, see notes above.
- 2. Remove drawers from other two units, attach bolts vertically through the casters holes.
- 3. Attach handles to middle cabinet.
- 4. Replace drawers into each cabinet after setting up right.
- 5. See Figure A-4 for final assembly of vertical cabinet.



Figure A-4

NOTE

If you have any questions about your Shopsmith Cabinets, please call our Customer Service Department TOLL-FREE at 1-800-762-7555, or drop us an e-mail at techsupport@shopsmith.com, or visit our website at www.shopsmith.com, or write to us at:

Shopsmith, Inc. Attn: Customer Service Technical Dept. 6530 Poe Avenue Dayton, Ohio 45414



09/04